



Smart LED Bulb

Quick Start Guide

Introduction

The Smart LED Bulb allows you to switch it ON and OFF and adjust its brightness and color temperature as well as set a switching from the mobile app.

Get started

To get started, you will need:


- A smart gateway
- A LED CCT Tunable LED Bulb
- The mobile app

Resetting the Smart Bulb

Toggle the power to the Smart LED Bulb LED bulb off, on, off, on, off, on, off, on, off, on, off, on (six on and six off) in slow succession. The LED will flash twice if it successfully returns to the factory default settings.

Then follow the steps below:-


1. Turn off the switch.
2. Fit the LED Bulb into the lamp socket.
3. Turn ON the switch and check if the LED Bulb flashes twice.
4. Turn OFF the Switch.
5. Open Maevi (Maevi Smart Home) app and go to “Home Automation” tab. Tap the plus circle at the below right of the screen to pair the Smart LED Bulb with the Gateway.



Tip: for this step, press the “Z” button on the gateway for 2 seconds until the LED indicator turns solid blue.







6. Turn ON the switch, the LED Bulb will flash twice.

7. The LED will try pair with the gateway, and it will flash once more when pairing is successful.



Scheduling Device

8. Create schedule to turn ON/OFF the Appliances.



Feature Apps

