



Maevi Smart LED Bulb
Quick Start Guide

Introduction

The Smart LED Bulb allows you to switch it ON and OFF, adjust its brightness and color temperature as well as set a switching from Maevi app.

Get started

To get started, you will need :

- Maevi Gateway
- Maevi Smart LED Bulb
- Maevi Mobile App


(Available for download on Google Play Store and Apple App Store)

Then follow the steps below:

1. Fit the Smart LED Bulb into the lamp socket.
2. Turn ON the switch and check if the Smart LED Bulb flashes twice.

Tip: If the Smart LED Bulb is not flashing twice, please turn off then turn on within 3 seconds and repeat this for 6 times, then the LED Bulb will flash twice when the device is return to default factory setting.

3. Open Maevi App and go to “Home Automation” tab.
4. Select “Add New Device” button to pair the Smart LED Bulb with the Gateway.




Tip: You can also press and hold the “Z” button on the Gateway for two seconds until the LED indicator turns steady blue.

5. The Smart LED Bulb will flash twice once more when pairing is successful.
6. The Smart LED Bulb should now appear in the app as LED Bulb. If not, refresh the “Home Automation” page by pull it down and release.
7. Click the LED Bulb to see individual info page.


Features

Info Tab – Brightness and Temperature Control / Remove Device / Rename Device / Device Info



Edit Button

Brightness and Temperature Control




To Remove Device

To Rename Device


Device Status/ Info

To Save Changes


Automation Tab - Create Schedule to turn On/Off Device




Select **Automation** tab,
tap
+ Add new automation schedule




Select status : **ON/OFF**




Select **Time**,
tap **Confirm**



Select **Day**,
tap **Confirm**



View details,
tap **Confirm**



Successful create
schedule

Reset Smart LED Bulb

Step:

1. Fit the Smart LED Bulb into the lamp socket.
2. Turn on the power supply.
3. Turn off then turn on the power supply within 3 seconds and repeat this for 6 times, (off, on, off, on, off, on, off, on, off, on, off, on) and the LED Bulb will turn warm light-cool light – warm light and flash once to indicate it has successfully return to default factory setting.